


Audi A6

Current Flow Diagram

No. 46 / 4



Automatic glow period control unit, glow plugs fuse, glow plugs

- J179 - Automatic glow period control unit
- Q10 - Glow plug 1
- Q11 - Glow plug 2
- Q12 - Glow plug 3
- Q13 - Glow plug 4
- S125 - Glow plug fuse
- T10w - 10-pin connector, black, in engine compartment
- 85 - Earth connection 1, in engine compartment wiring harness
- \* - Relay carrier electronics box on right in plenum chamber

ws = white  
sw = black  
ro = red  
br = brown  
gn = green  
bl = blue  
gr = grey  
li = purple  
ge = yellow  
or = orange  
rs = pink

Audi A6

Current Flow Diagram

No. 46 / 5